

Service Bulletin

Safety Wire Gasculator Bowl Assembly

ADVISORY

Symbols:

Please pay special attention to the following symbols emphasizing particular information throughout this document.

- ▲ WARNING: Identifies an instruction, which if not followed, may cause serious injury or even death.
- ◆ CAUTION: Denotes an instruction, which if not followed, may severely damage the aircraft or could lead to suspension of factory warranty.
- **★** NOTE: Information useful to implement the change more easily.

1. General

Issued by: Powrachute, LLC. 3001 West Airport Road, Hastings, MI 49058

Web: www.powrachute.com Ph: 574-286-9670

Release Date: Aug 25, 2008

<u>Date of Effect:</u> Immediately

<u>Compliance:</u> Before Next Flight

Release Number: 08-25-08-1

Superseded Notice: None

Models Effected: Pegasus 582 and Airwolf 912ULS

Affected S/N: Any and All Pegasus 582 and Airwolf 912ULS with Gasculators Installed.

Reason: Without safety wire the bowl could become loose and leak fuel.

<u>Subject:</u> Inspection and adding safety wire.

<u>Time required:</u> 1 Minute for Inspection and 5 Minutes for proper safety wire.

2. Material Information

Tools needed: For Inspection none, for replacement safety wire plyers

<u>Parts Needed:</u> Safety Wire.

3. Compliance

<u>License required:</u> For Inspection, Owner or Pilot In Command

For Replacement on S-LSA:

LSA Repairman, A&P Mechanic, Part 145 Repair Station or Owner.

<u>Certification:</u> None

4. Instructions for Inspection

See if safety wire is present. If not this would apply.

5. Instructions

Safety Wire the Bowl to the top housing.

6. Advise

Bowl might come loose with vibration. This will cause the fuel to drain out of the Gasculator bowl and starve the engine of fuel.